




KISS


1/4" Turn Double Rake Using Washers

<http://www.kiss-looms.com/>




Let's take a look at a KISS Rake. When we look at the rake from the end we can see there are a narrow side and a wide side in relationship to the peg. KISS looms are made intentionally this way to aid in being an adjustable loom.

When using KISS Double Rakes with washers to get the same setting as if you were using the double rakes with the blocks you will need to use 16 washers between double rakes.



Here you see "Setting 1". Setting 1 has narrow sides facing toward each other and 16 washers between.



Here you see "Setting 2". Setting 2 has a wide side and a narrow side facing toward each other and 16 washers between.






Setting 2

KISS

1/4" Turn Double Rake Using Washers

<http://www.kiss-looms.com/>



Setting 3

Here you see "Setting 3". Setting 3 has both wide sides facing toward each other and 16 washers between.

You can change the gauge of your double knit by using a combination of narrow/wide sides and various numbers of washers between the double rakes. However I would caution you that at 8 washers (1/4") you will want to make sure you use an anchor yarn to help advance your fabric between the double rakes. You should make sure to use an anchor yarn when using smaller gauges, some caution to always use an anchor yarn.

